Perkins engines

OPERATORS MANUAL FOR MARINE DIESEL ENGINES

4.108	6.354	T6.354MGT
4.154	T6.354	V8.510
4.236	HT6.354	TV8.510

PRINTED U.S.A.

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

INTRODUCTION 4
ENGINE IDENTIFICATION 7
ENGINE PHOTOGRAPHS 12
ENGINE SPECIFICATIONS 28
INSTRUMENTS 30
STARTING AND STOPPING ENGINE 31
SCHEDULED MAINTENANCE 34
ENGINE PRESERVATION 42
COLDWEATHER PRECAUTIONS 45
FUEL SYSTEM 45
COOLING SYSTEM 54
LUBRICATING SYSTEM 56
LUBRICATING OIL SPECIFICATIONS 58
GEARBOXES (TRANSMISSIONS) 59
CHECKING VALVE TIP CLEARANCES 61
ELECTRICAL SYSTEM 62
EMERGENCY MAINTENANCE AND OPERATING TIPS 64
ONBOARD TOOLS AND SPARE PARTS 65
TROUBLESHOOTING 67
INDEX 68

Downloaded from www.Manualslib.com manuals search engine

ENGINE IDENTIFICATION LOCATION

A. V8.510, TV8.510

B. 4.108, 6.354, T6.354
HT6.354, T6.354 MGT

C. 4.236


D. 4.154

E. 4.154 (Newer Engines)
4.236 (Newer Engines)

A. Top-Front Cyl. Block, R.H. Cyl.Bank

B. Fuel Pump Mounting Flange, L.H.

C. Front Cyl. Block, R.H.



D. Rear-Top Cyl. Block, L.H.

E. Front Cyl. Block, L.H.

"R.H."= Right Hand or Alternator Side

"L.H."= Left Hand, Fuel Injection, Pump Side

Note:

Left and right hand locations are given assuming that the engine is viewed from the rear.

Downloaded from www.Manualslib.com manuals search engine

The location of the identification code, as applicable to each engine, is depicted in the following series of illustrations (fig. 2a through fig. 2e). When information, replacement parts or assistance is required, the complete engine identification code should always be quoted.




Fig. 2 (a)

Engine Identification Location
4.108




Fig. 2 (b)

4.154 Engine Identification Location. Rear-Top of Cylinder Block, Left-Hand Side of Engine. Newer Engines: Left-Hand Side of Engine, above fuel injection pump.

Downloaded from www.Manualslib.com manuals search engine